



User Manual








ULTRALIGHT TRAVEL HAMMOCK





Contents

Overview	3
Use.....	4
Package contents/product parts	6
General information.....	7
Reading and storing the user manual	7
Explanation of symbols	7
Safety	8
Scope of use.....	8
Safety instructions.....	8
Checking the hammock and package contents	10
Firmly secure the hammock to each tree.....	11
Using the hammock	12
Cleaning	13
Storage	13
Technical data	14
Disposal.....	14
Disposal of the packaging	14
Disposing of the hammock.....	14







Package contents/product parts

- 1 Carabiner clips, 2×
- 2 Rope, 2×
- 3 Protective bag

General information

Reading and storing the user manual



This user manual accompanies the ultralight travel hammock (referred to below only as the “hammock”). It contains important information for assembly and use.

Before using the hammock, read the user manual carefully. This particularly applies to the safety instructions. Failure to heed this user manual may result in severe injury, or damage to the hammock.

The user manual is based on the standards and regulations in force in the European Union. When abroad, you must also observe country-specific guidelines and laws.

Store the user manual for future use. If you pass the hammock on to third parties, please be absolutely sure to include this user manual.

Explanation of symbols

The following symbols and signal words are used in this user manual, on the hammock or on the packaging.



This signal symbol/word designates a hazard with moderate degree of risk which may lead to death or severe injury if not avoided.



This signal symbol/word designates a hazard with low risk that, if not avoided, may result in minor or moderate injury.



This signal word warns against potential damages to property.



This symbol provides you with useful additional information regarding assembly or use.



The maximum weight-loading amounts to 150 kg.



Dimensions of the hammock: 275 × 150 cm.

Safety

Scope of use

This hammock has been designed as a comfortable and relaxing place for one person to lie down, and has a maximum weight-loading of 150 kg. It is only intended for private use and is not suitable for commercial purposes.

Only use the hammock as described in this user manual. Any other use is deemed improper and may result in damage to property or even personal injury. The hammock is not a children's toy.

The manufacturer or vendor accepts no liability for damage caused by improper or incorrect use.

Safety instructions



Risk of strangulation and suffocation!

If children play with the hammock or the packaging, they could get caught in it or thus become strangulated and suffocate.

- Do not allow children to play with the packaging wrapper or the hammock.
- Supervise children close to the hammock.



Risk of injury!

Incorrect use of the hammock may result in injury.

- Do not exceed the hammock's load bearing capacity of 150 kg.
- Always make sure that only one person is using the hammock at any one time.
- Do not stand on the hammock.
- Do not jump into the hammock and do not let yourself fall into in the hammock.

-
- Do not use the hammock to store books and similar items.
 - Do not use the hammock to transport any animals or objects.
 - Do not use the hammock as a swing.
 - Do not let children use the hammock if they are not supervised.
 - Do not use the hammock as a climbing aid.
 - Each time before use, check the hammock and all fastening elements for damage. Do not use the hammock when the hammock or individual parts are damaged.
 - Do not lie down in the hammock until it has been properly set up, fixed and secured.
 - Set the hammock up only above soft surfaces. If you do so and fall out of the hammock, you will not be as seriously injured.
 - Do not use the hammock during a storm.
 - Have qualified professionals perform repairs. Liability and warranty claims are waived in the event of repairs performed by the user, or incorrect use.

NOTICE!

Risk of damage!

Improper handling of the hammock may damage the hammock.

- Do not leave the hammock to hang unattended after use.
- Stop using the hammock if it is cracked, torn, or individual parts are damaged. Only replace damaged individual parts with corresponding original spare parts.
- Always keep the hammock away from fires and cigarettes.

Checking the hammock and package contents

NOTICE!

Risk of damage!

If you are not cautious when opening the packaging with a sharp knife or other pointed objects, the hammock may become damaged.

– Be careful when opening the package.

1. Remove the hammock from the package.
2. Check to make sure that the delivery is complete (see **Fig. A**).
3. Check whether the hammock or the individual parts exhibit any damage.
If this is the case, do not use the hammock. Contact the manufacturer at the service address specified on the warranty card.

Firmly secure the hammock to each tree



Risk of injury!

Incorrect use of the hammock may result in injury.

- Only adults must be allowed to set up the hammock.
- Do not lie down in the hammock until it has been properly set up, fixed and secured.
- Make sure that the surface underneath is as soft as possible.
- Remove pointed and sharp stones and other sharp objects from the surface underneath the hammock.
- Spread the hammock out so that it is about 2.5 m in length.



Fix and secure the hammock between two sturdy trees. These should be spaced approx. 3 m apart.

1. Remove the hammock from the protective bag **3**.
2. Unfold the hammock and spread it out on the ground.
3. Take a piece of rope, **2** double it and lay it down so that both ends of the rope precisely meet.
4. Make a knot at the top of the ends of the rope (see **Fig. D**).
5. Wrap the rope twice around a tree (see **Fig. E**).
6. Pull the knot through the loop and tighten the loop (see **Fig. F**).
7. Attach one of the carabiner clips **1** to the rope (see **Fig. G**).
8. Repeat steps 3 to 7 with the second support rope and carabiner clips to the tree opposite.
9. Spread the hammock out so that it is approx. 2.5 m in length. If there is a person in the hammock, the distance between the hammock and the ground must not be more than 0.5 m.

Using the hammock



Risk of injury!

Correctly lie down in the hammock, to prevent injuries, and also damage to the hammock.

- It must always be made sure that the distance between the hammock and the ground is not more than 0.5 m.
- Spread the hammock out so that it is about 2.5 m in length.
- Do not lie down in the hammock until it has been properly set up, fixed and secured.
- Each time before use, check the hammock and all fastening elements for stability, damage, and wear and tear. Do not use the hammock when the hammock or individual parts are damaged.
- Do not leave the hammock to hang unattended after use.



- Make sure that the hammock is not stretched out too tightly and lie down slightly diagonally in the hammock. This ensures healthy and correct back posture (see **Fig. B**)
- Lie down slightly horizontally in the hammock, and make sure that the hammock is not stretched out too tightly (see **Fig. C**).

1. Place yourself on one side of the hammock.
2. Swing a leg over the hammock so you are lying in the hammock with your legs apart.
3. Now lay back in the hammock.
4. Carefully swing your legs up into the hammock.
5. Lean your upper body back.

Cleaning

NOTICE!

Risk of damage!

The hammock may become damaged if it is improperly handled.

- Do not use any aggressive cleaners, brushes with metal or nylon bristles or sharp or metallic cleaning utensils such as knives, hard scrapers and the like. They could damage the surfaces.
- Do not in any case place the hammock in the washing machine.
- Wipe the hammock, the carabiner clips **1** and the ropes **2** with a damp cloth.
- Then let the hammock and, if necessary, the individual parts dry completely.

Storage

1. Clean the hammock as described in the chapter “Cleaning”.
2. Store the hammock in the protective bag **3**.
3. Store the hammock in a dry place inaccessible to children.

Technical data

Model:	FLX-LH-01
Material:	Polyamide with CIRE – coating
Weight:	approx. 610 g
Maximum load:	150 kg
Dimensions of the hammock:	2.75 m × 1.5 m
Dimensions, rope:	each 4 m
Article number:	94789

As our products undergo continual development and improvement, technical changes and changes to the product design are possible.

This user manual can also be downloaded as a PDF file from our homepage

www.flexxtrade.de.

Disposal

Disposal of the packaging



Dispose of the packaging separated into single type materials. Dispose of cardboard and carton as waste paper and film via the recyclable material collection service.

Disposing of the hammock

Dispose of the hammock in accordance with the disposal laws and regulations in force in your country.



Great care has gone into the manufacture of this product and it should therefore provide you with years of good service when used properly. In the event of product failure within its intended use over the course of the first 3 years after date of purchase, we will remedy the problem as quickly as possible once it has been brought to our attention. In the unlikely event of such an occurrence, or if you require any information about the product, please contact us via our helpline support services, details of which are to be found both in this manual and on the product itself.



PRODUCED IN CHINA FOR:

ALDI STORES LTD. PO BOX 26, ATHERSTONE
WARWICKSHIRE, CV9 2SH.

ALDI STORES (IRELAND) LTD.
PO BOX 726, NAAS, CO. KILDARE.
Visit us at www.aldi.com

AFTER SALES SUPPORT

94789



GB IRE 00800 / 78747874



GB flexxtrade-gb@teknihall.com

IRE flexxtrade-ie@teknihall.com

MODEL:
FLX-LH-01

05/2017

3
YEARS
WARRANTY